

---

## Security CLI Reference

CLI commands for configuring and monitoring security.

---

## Security Configuration Commands

Use the following commands to configure security parameters:

```
security
  control
    protocol (dtls | tls)
    tls-port number
  ipsec
    authentication-type type
    rekey seconds
    replay-window number
```

---

## Security Monitoring Commands

[show control connections](#)

[show security-info](#)

---

## Additional Information

[Security Overview](#)

[Configuring Security Parameters](#)

